



HLP 4800 Platform

Quick Start Guide

VERSION 1.0

Disclaimer

Harmonic reserves the right to alter the equipment specifications and descriptions in this publication without prior notice. No part of this publication shall be deemed to be part of any contract or warranty unless specifically incorporated by reference into such contract or warranty. The information contained herein is merely descriptive in nature, and does not constitute a binding offer for sale of the product described herein. Harmonic assumes no responsibility or liability arising from the use of the products described herein, except as expressly agreed to in writing by Harmonic. The use and purchase of this product do not convey a license under any patent rights, copyrights, trademark rights, or any intellectual property rights of Harmonic. Nothing hereunder constitutes a representation or warranty that using any products in the manner described herein will not infringe any patents of third parties.

Trademark Acknowledgments

Harmonic and all Harmonic product names are trademarks of Harmonic Inc. All other trademarks are the property of their respective owners.

Compliance and Approval

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15, Subpart B of the Federal Communications Commission (FCC) rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy. It may cause harmful interference to radio communications if it is not installed and used in accordance with the instructions in this manual. Operation of this equipment in a residential area is likely to cause harmful interference. If this occurs, the user will be required to correct the interference at his or her own expense.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Connections between the Harmonic equipment and other equipment must be made in a manner that is consistent with maintaining compliance with FCC radio frequency emission limits. Modifications to this equipment not expressly approved by Harmonic may void the authority granted to the user by the FCC to operate this equipment.

Compliance with 21CFR 1040 and 1040.10



Complies with 21 CFR 1040.10 and 1040 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.



When you work with this equipment, take the following precautions:

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Never look at an optical fiber using a direct magnification fiber scope without verifying that all lightwave sources on the fiber are turned off.

Never look directly into an optical connector.

Install protective covers or caps over connectors when they are not being used.

Always assume that exposed optical connectors and cables are energized.

Always make an optical power measurement of the fiber or connector before cleaning or before visual inspection, to ensure that the fiber is not energized.



Lorsque vous travaillez avec ce matériel, prenez les précautions suivantes:

L'utilisation de commandes ou de réglages ou l'utilisation de procédures autres que celles décrites dans ce manuel d'utilisation peut générer une exposition à des radiations dangereuses.

Ne jamais regarder une fibre optique directement avec un outil d'inspection de fibres sans vérifier que toutes les sources lumineuses dans la fibres sont éteintes.

Ne jamais regarder directement à un connecteur de fibre optique.

Installer les bouchons protecteurs sur les connecteurs qui ne sont pas utilisés.

Toujours supposer qu'un connecteur exposé ou une fibre optique émettent de l'énergie lumineuse.

Toujours mesurer la puissance optique d'une fibre optique ou d'un connecteur avant de le nettoyer une inspection visuelle pour s'assurer que la fibre n'émet pas d'énergie lumineuse.



Beim Arbeiten mit diesem Gerät, beachten Sie die folgenden Vorsichtsmaßnahmen:

Die Verwendung von Reglern oder Einstellungen sowie die Durchführung von Verfahren die hier nicht beschrieben sind kann dazu führen das Sie gefährlicher Strahlung ausgesetzt werden.

Blicken Sie nie mit einem Lichtwellenleiter Microscope in einen Lichtwellenleiter, ohne zu prüfen, dass alle Laserquellen auf dem Lichtwellenleiter deaktiviert sind.

Blicken Sie nie direkt in einen optischen Anschluss.

Installieren Sie Schutzabdeckungen oder Kappen über Lichtwellenleiteranschlüssen, wenn sie nicht verwendet werden.

Gehen Sie immer davon aus, dass optische Anschlüsse und Kabel aktiv sind.

Führen Sie immer eine optische Messung am Lichtwellenleiter oder Stecker durch bevor Sie einen optischen Anschluss reinigen oder inspizieren, um sicherzustellen, dass er nicht aktiv ist.



Power Supply Cord Notice

CAUTION – This unit has more than one power supply connection; all connections must be removed to remove all power from the unit.

ATTENTION – Cette unité est équipée de plusieurs raccordements d'alimentation. Pour supprimer tout courant électrique de l'unité, tous les cordons d'alimentation doivent être débranchés.

WARNUNG – Diese Einheit verfügt über mehr als einen Stromanschluß; um Strom gänzlich von der Einheit fernzuhalten, müssen alle Stromzufuhren abgetrennt sein.

CAUTION – The power supply cord is used as the main disconnect device, ensure that the socket outlet is located/installed near the equipment and is easily accessible.

ACHTUNG – Zur sicheren Trennung des Gerätes vom Netz ist der Netzstecker zu ziehen. Vergewissern Sie sich, daß die Steckdose leicht zugänglich ist.

ATTENTION – Le cordon d'alimentation est utilisé comme interrupteur général. La prise decourant doit être située ou installée à proximité du matériel et être facile d'accès.



AC Version

WARNING – This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that a fuse or circuit breaker no larger than 120 VAC, 15A U.S. (240 VAC, 10A international) is used on the phase conductors (all current-carrying conductors).

ATTENTION – Pour ce qui est de la protection contre les courts-circuits (surtension), ce produit dépend de l'installation électrique du local. Vérifier qu'un fusible ou qu'un disjoncteur de 120 V alt., 15 A U.S. maximum (240 V alt., 10 A international) est utilisé sur les conducteurs de phase (conducteurs de charge).

WARNUNG – Dieses Produkt ist darauf angewiesen, daß im Gebäude ein Kurzschluß- bzw. Überstromschutz installiert ist. Stellen Sie sicher, daß eine

Sicherung oder ein Unterbrecher von nicht mehr als 240 V Wechselstrom, 10 A (bzw. in den USA 120 V Wechselstrom, 15 A) an den Phasenleitern (allen stromführenden Leitern) verwendet wird.



DC Version

Warning: This product relies on the building's installation for short-circuit (overcurrent) protection. Ensure that a fuse or circuit breaker no larger than 15A is used on the phase conductors (all current-carrying conductors).

Attention: Pour ce qui est de la protection contre les courts-circuits (surtension), ce produit dépend de l'installation électrique du local. Vérifier qu'un fusible ou qu'un disjoncteur de 15A est utilisé sur les conducteurs de phase (conducteurs de charge).

Warnung: Dieses Produkt ist darauf angewiesen, daß im Gebäude ein Kurzschluß- bzw. Überstromschutz installiert ist. Stellen Sie sicher, daß eine Sicherung oder ein Unterbrecher von nicht mehr 15A an den Phasenleitern (allen stromführenden Leitern) verwendet wird.

Lithium Battery Notice

CAUTION – Danger of explosion if battery is replaced with incorrect type. Replace only with the same type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

ACHTUNG – Explosionsgefahr wenn die Battery in umgekehrter Polarität eingesetzt wird. Nur mit einem gleichen oder ähnlichen, vom Hersteller empfohlenen Typ, ersetzen. Verbrauchte Batterien müssen per den Instructionen des Herstellers verwertet werden.

ATTENTION – Il y a danger d'explosion s'il a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du meme type ou d'un type equivalent recommande par le constructeur. Mettre au rebut les batteries usages conformement aux instructions du fabricant.

Chassis Warning--Rack-Mounting and Servicing

WARNING –To prevent bodily injury when mounting or servicing this unit in a rack, you must take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:

- This unit should be mounted at the bottom of the rack if it is the only unit in the rack.
- When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
- If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.

ATTENTION – Pour éviter toute blessure corporelle pendant les opérations de montage ou de réparation de cette unité en casier, il convient de prendre des précautions spéciales afin de maintenir la stabilité du système. Les directives ci-dessous sont destinées à assurer la protection du personnel :

- Si cette unité constitue la seule unité montée en casier, elle doit être placée dans le bas.
- Si cette unité est montée dans un casier partiellement rempli, charger le casier de bas en haut en plaçant l'élément le plus lourd dans le bas.
- Si le casier est équipé de dispositifs stabilisateurs, installer les stabilisateurs avant de monter ou de réparer l'unité en casier.

WARNUNG – Zur Vermeidung von Körperverletzung beim Anbringen oder Warten dieser Einheit in einem Gestell müssen Sie besondere Vorkehrungen treffen, um sicherzustellen, daß das System stabil bleibt. Die folgenden Richtlinien sollen zur Gewährleistung Ihrer Sicherheit dienen:

- Wenn diese Einheit die einzige im Gestell ist, sollte sie unten im Gestell angebracht werden.
- Bei Anbringung dieser Einheit in einem zum Teil gefüllten Gestell ist das Gestell von unten nach oben zu laden, wobei das schwerste Bauteil unten im Gestell anzubringen ist.
- Wird das Gestell mit Stabilisierungszubehör geliefert, sind zuerst die Stabilisatoren zu installieren, bevor Sie die Einheit im Gestell anbringen oder sie warten.

Precautions When Configuring the Equipment Rack:

When operating the unit in an equipment rack, take the following precautions:

- Make sure the ambient temperature around the unit (which may be higher than the room temperature) is within the limit specified for the unit.
- Make sure there is sufficient airflow around the unit.
- Make sure electrical circuits are not overloaded – consider the nameplate rating of all the connected equipment, and make sure you have over current protection.
- Make sure the equipment is properly grounded.
- Make sure no objects are placed on top of the unit.

WEEE/RoHS Compliance Policy

Harmonic Inc. intends to comply fully with the European Union's Directive 2002/96/EC as amended by Directive 2003/108/EC, on Waste Electrical and Electronic Equipment, also known as "WEEE," and Directive 2002/95/EC, as amended, on the Restriction of use of Hazardous Substances, also known as "RoHS."

For more information about Harmonic's Green Policy, please visit our website under the "About Us" section (www.harmonicinc.com).

Harmonic will ensure that product which cannot be reused will be recycled in compliance with the WEEE Directive. To that end, users are advised that (1) Harmonic equipment is not to be discarded in household or office garbage, (2) Harmonic Inc. will pay the freight for shipment of equipment to be disposed of if it is returned to Harmonic, (3) customers should call the normal RMA telephone numbers to arrange for such shipment, and (4) for additional and updated information on this process customers may consult the Harmonic website: http://harmonicinc.com/ah_weene_recycle.cfm.

Harmonic will ensure that its products will be either reused or recycled in compliance with the WEEE Directive. For the latest information concerning Harmonic's WEEE/RoHS Compliance Policy and its Recycling and Take-Back process, please visit our web site.



Standards

The following tables list regulatory standards and approvals:

North America

Standards

EMI: FCC Part 15, Subpart B, ICES-003, Issue 2, Class A

Safety: UL 60950-1, CSA C22.2 No 60950-1, 21 CFR 1040 (CDRH)

Europe

Standards

EMI/EMC: EN55022, EN55024, EN61000-3-2, EN61000-3-3

Safety: EN 60950-1, EN 60825-1

Japan

Standards

EMI: VCCI V-3 / 2007.04

Australia and New Zealand

Standards

EMI: AS/NZS-CISPR 22:2005

Documentation Conventions

This manual uses some special symbols and fonts to call your attention to important information. The following symbols appear throughout this manual:



DANGER: The Danger symbol calls your attention to information that, if ignored, can cause physical harm to you.



CAUTION: The Caution symbol calls your attention to information that, if ignored, can adversely affect the performance of your Harmonic product, or that can make a procedure needlessly difficult.



LASER DANGER: The Laser symbol and the Danger alert call your attention to information about the lasers in this product that, if ignored, can cause physical harm to you.



NOTE: The Note symbol calls your attention to additional information that you will benefit from heeding. It may be used to call attention to an especially important piece of information you need, or it may provide additional information that applies in only some carefully delineated circumstances.



TIP: The Tip symbol calls your attention to parenthetical information that is not necessary for performing a given procedure, but which, if followed, might make the procedure or its subsequent steps easier, smoother, or more efficient.

In addition to these symbols, this manual uses the following text conventions:

- `Data Entry`: indicates text you enter at the keyboard.
- `User Interface`: indicates a button to click, a menu item to select, or a key or key sequence to press.
- `Screen Output`: shows console output or other text that is displayed to you on a computer screen.
- **Bold**: indicates the definition of a new term.
- *Italics*: used for emphasis, cross-references, and hyperlinked cross-references in online documents.

Table of Contents

Chapter 1	Getting Started with the HLP 4800	
1.1	System Overview	13
1.2	HLP 4800 Chassis	14
1.3	HLP 4800 Front Panel	15
1.4	HLP 4800 Rear Panel	16
1.5	HNC Front Panel	17
1.5.1	Front Panel LED	17
1.5.2	Front Panel Soft Reset	17
1.5.3	Navigation Keys and Menu System	18
Chapter 2	Installing the HLP 4800	
Chapter 3	Contacting Harmonic, Inc	
3.1	Contacting Harmonic Support	22
Appendix A	Technical Specifications	

This instruction manual is a quick start guide for the HLP 4800 Platform. Please read the entire document before beginning installation or operation.

1.1 System Overview

The HLP 4800 is Harmonic's new flexible platform for mounting broadband communications equipment.

The HLP 4800 Platform is used with a number of plug-in modules, such as the PWRLink™ series of 1310 nm laser transmitters and the SUPRALink™ series of 1550 nm DWDM laser transmitters, as well as the HRM3811 receiver, the METROLink™ series of 1550nm narrowcast DWDM transmitters, and optical switches.

The new HLP 4800 Platform is designed to meet the economic and technical requirements of broadband service providers. The modular design of the product offers the user a number of advantages, including:

- The flexibility to add plug-in modules as industry requirements change, without the need to replace equipment shelves, power supplies or status monitoring equipment.
- The economic advantage of maintaining spare plug-in modules rather than entire subsystems.
- Reduced network downtime because of plug-in module replacements.

1.2 HLP 4800 Chassis

The HLP 4800 is a rack-mount platform, three rack-units in height, and designed to be fitted to a 19-inch EIA standard rack flange. It will accommodate ten of Harmonic's standard 1.3 inch wide plug-in modules, using appropriate carriers.

A typical configuration would contain one or two CPS 4800 power supply modules and one HNC4800 controller with display and keypad, as well as other Harmonic modules.

Controlling and monitoring of the HLP 4800 and modules is accomplished by the following means:

- Local control and monitoring using the momentary push buttons and forty character display on the front panel of the HNC 4800
- Remote control and monitoring by means of license-enabled WEB/SNMP RJ-45 Ethernet interface on the rear of the HNC 4800.
- The forty-character display on the platform front panel provides the following:
 - Name and slot position of each module contained within the Platform.
 - Network address setting.
 - Control and Diagnostic menus for each module in the Platform.

1.3 HLP 4800 Front Panel

Figure 1-1 on page 15 shows the HLP 4800 front panel features and locations.




Figure 1-1: HLP 4800, front panel

The HNC 4800 controller 40-character display provides the following:

- ❑ Name and slot position of each module contained within the Platform.
- ❑ Network address settings.
- ❑ Control and diagnostic menus for each module in the Platform.

Use the five push-button keys to navigate the menus that display and set properties:

- ❑ ESC
- ❑ SET
- ❑ Down
- ❑ UP
- ❑ Enter

Two CPS 4800 power supplies can be inserted.

Five full slots can accommodate up to ten half-slot (1.3") modules.

1.4 HLP 4800 Rear Panel

Figure 1-2 on page 16 shows the rear panel of the HLP 4800.




Figure 1-2: HLP 4800, rear panel

1.5 HNC Front Panel

After the HNC 4800 is installed in the dedicated controller slot of the HLP 4800, you can use the momentary push buttons and forty-character display on the front panel to control and monitor the HNC 4800 and the HLP 480 plug-in (consistency) modules.

Figure 1-3 on page 17 shows the HNC front panel.




Figure 1-3: HNC 4800 front panel

1.5.1 Front Panel LED

There is one status LED on the front panel. The Status LED indicates the alarm state of the HNC 4800 and associated modules. Solid green indicates the unit is operating normally; red indicates an active alarm.

1.5.2 Front Panel Soft Reset

There is a controller soft-reset pinhole on the front panel. Access it using a bent paper clip.

1.5.3 Navigation Keys and Menu System

There are six high-level menus on the HNC, and four navigation keys to select among them.

The menu system high-level choices are:

- System Ready
- Module Selection
- Address
- Contrast
- Backlight
- Power Supply

Figure 1-4 shows the menus, starting with System Ready.




Figure 1-4: Front panel menus

Use the navigation keys to move through the menus and submenus:


- **Down-arrow** moves down the list.
- **Up-arrow** moves up the list.
- **Enter** moves you deeper into the menu structure.
- **ESC** returns to your previous selection.

Three manuals contain instructions for the proper installation of the HLP 4800 system.

Table 2-1: HLP 4800 manual set

Manual Title	Part Number
HLP 4800 User's Guide	700-0052028
CPS 4800 Power Supply User's Guide	700-0052029
HNC 4800 Controller User's Guide	700-0052031

To get copies of the manuals, go to www.harmonicinc.com/myharmonic, and log in, using a valid login for the Harmonic Extranet.



Search for HLP 4800, and navigate to the product page. Use the links there to download the product manuals in PDF format.

If you do not have a login, contact Harmonic support. (See Chapter 3, *Contacting Harmonic, Inc.*)



CAUTION: Read all instructions before beginning installation.

3.1 Contacting Harmonic Support

The Harmonic Customer and Technical Support groups are available to help you with any questions or problems you may have regarding Harmonic products.

For assistance from within the U.S. and Canada, call toll free:

1.888.MPEGTWO (673.4896)

For assistance from outside the U.S. and Canada, call:

1.408.490.6477

The fax number is 408.490.6770.

The email address is techhelp@harmonicinc.com.

The corporate address for Harmonic Inc. is:

Harmonic Inc.
549 Baltic Way
Sunnyvale, CA 94089, U.S.A.
Attn: Customer Support

The corporate telephone numbers for Harmonic Inc. are:

Tel. 1.800.788.1330 (from the U.S. and Canada)

Tel. +1.408.542.2500 (outside the U.S. and Canada)

Fax.+1.408.490.6708

The web address for Harmonic Inc. is www.harmonicinc.com.

Appendix A

Technical Specifications

HLP 4800 Technical specifications:

Physical

Dimensions	19" W x 5.25" H x 13" D 48.3 cm W x 13.3 cm H x 33.02 cm D
Weight (without modules)	17.25 lbs 7.84 kg
Mounting 19" EIA rack, 3 RU spaces	

Power Requirements

Back-up Input Voltage	+24 VDC
-----------------------	---------

Electrical

Backplane Current Capacity	11 Amps max.
----------------------------	--------------

Environmental

Operating Temperature Range	+32° to +122° F 0° to +50° C
Storage Temperature Range	-40° to +85° C -40° to +185° F
Relative Humidity Maximum	95% non-condensing

User Interface

Rear Panel

Alarm activated relay contact

+24 VDC backup

Grounding nut

Part Numbers

HLP 4800	Chassis
HNC 4800	Display and controller
CPS 4800-AC	AC power supply
CPS 4800-DC	DC power supply
FW-HNC 4800-WEB/SNMP	WEB/SNMP license

Harmonic Inc.

549 Baltic Way
Sunnyvale, CA 94089, U.S.A.

T +1 408 542 2500

F +1 408 490 6708

www.harmonicinc.com